



ACTIVITY OPERATION



Select an activity from the home page by touching its icon. For activities that support **distributed audio**, you are then presented with a Room Grid (layouts for 6, 12, 18, and 28 rooms are included). Touch all the rooms you want the activity to play in and press the "Close" button. To edit your selection, simply touch the "Rooms..." button to pull up the room list again, and touch any room to toggle it on or off.

QUICK KEYS™



Quick Keys are always on screen and allow you to access special functions without navigating away from your main activity. Use them for operating cameras, climate, house scenes, lighting, security, window treatments, and more.

For **multi-zone operations**, Quick Keys may be used to pull up a flexible Room Grid which can, for example, toggle the lights on and off or display current temperatures in different zones.